



version: 20-06-2013

cod. 7NU0311GAB58-V

IT	MANUALE d'USO e MANUTENZIONE armadio abbattitore/congelatore.....	pagina 3
EN	USE AND MAINTENANCE MANUAL blast chiller/shock freezer.....	page 19
IT	SETPOINT e PARAMETRI abbattitore/congelatore.....	pagina 36
EN	SETPOINT and PARAMETERS blast chiller/shock freezer.....	page 40
IT	SPECIFICHE TECNICHE - SCHEMI ELETTRICI	pagina 45
EN	TECHNICAL SPECIFICATION - WIRING DIAGRAMS	page 45

TABLE OF CONTENTS

1. STANDARDS AND GENERAL INSTRUCTIONS

- 1.1. Testing
- 1.2. Warranty
- 1.3. Introduction
- 1.4. Prerequisites supplied by the customer
- 1.5. Instructions regarding requests for intervention
- 1.6. Instructions for spare parts

2. TECHNICAL DATA

- 2.1. Noise level
- 2.2. Materials and fluids used

3. OPERATION

- 3.1. Applications, purpose, declared and non-declared use, authorised use
- 3.2. Dangerous areas
- 3.3. Safety devices

4. ROUTINE AND PROGRAMMED MAINTENANCE

- 4.1. Elementary safety standards
- 4.2. Instructions regarding emergency operations in the case of fire
- 4.3. Cleaning the machine
- 4.4. Periodic checks
- 4.5. Precautions in the case of extended periods of inactivity
- 4.6. Extraordinary maintenance

5. DISPOSAL

- 5.1. Disconnection
- 5.2. Storage
- 5.3. Dismantling and disposal

6. INSTALLATION

- 6.1. Transport and handling of the product
- 6.2. Description of commissioning operations
- 6.3. Positioning
- 6.4. Connection
- 6.5. Re-installation

7. USER INSTRUCTIONS

- 7.1. Control panel
- 7.2. Clock programming according to HACCP
- 7.3. Operational cycles
 - 7.3.0. Switch on
 - 7.3.1. Pre-cooling
 - 7.3.2. Soft or hard blast chilling cycle +37°F and soft or hard shock freezing 0F°C with core probe
 - 7.3.3. Soft or hard +37°F blast chilling cycle and soft or hard 0F°C shock freezing with timing
 - 7.3.4. Blast chilling/shock freezing cycle with multipoint core probe suitable for products with thickness over 90 mm
 - 7.3.5. Blast chilling/shock freezing cycle with 2 – 3 – 4 standard core probes
 - 7.3.6. Evaporator fan speed setting
 - 7.3.7. Customised blast chilling or shock freezing
 - 7.3.8. Indefinite time cycle with cabinet setpoint setting
 - 7.3.9. Conservation phase
 - 7.3.10. Memorising a blast chilling/shock freezing program
 - 7.3.11. Recall of memorised blast chilling/shock freezing program
- 7.4. Defrosting
- 7.5. Sterilisation (optional)
- 7.6. Printer (optional)
- 7.7. Alarms/errors
 - 7.7.0. Alarm absence communication between base and keyboard
 - 7.7.1. High temperature alarm
 - 7.7.2. Low temperature alarm
 - 7.7.3. Door open alarm
 - 7.7.4. Pressure switch alarm
 - 7.7.5. Time out alarm
 - 7.7.6. Blackout alarm
 - 7.7.7. Low pressure water alarm
 - 7.7.8. Cabinet probe alarm
 - 7.7.9. Core probe alarm
 - 7.7.10. Evaporator probe alarm
- 7.8. HACCP
 - 7.8.1. HACCP alarm re-set
 - 7.8.2. RICS software connection

1. STANDARDS AND GENERAL INSTRUCTIONS

1.1. TESTING

The product is dispatched after visual, electrical and operating tests have been passed.

1.2. WARRANTY

The warranty on the machine and related parts we manufacture is valid for a period of 1 year from the date of invoice and consists of the free supply of spare parts which, according to our final judgement, are deemed to be faulty.

It is the responsibility of the manufacturer to eliminate any faults and defects on condition that the machine has been correctly used in accordance with the instructions provided in the manual.

During the warranty period the customer will be responsible for costs related to labour, travel or transfers, transport of the parts and any equipment to be replaced.

The items replaced under warranty remain our property and must be returned by the customer at the his own expense.

1.3. INTRODUCTION

This manual is intended to provide all the necessary information for correct installation, operation and maintenance of the machine by qualified personnel.


Read the instructions provided carefully prior to any operation, as these contain essential safety indications concerning the machine.


THE MANUFACTURER DECLINES LIABILITY FOR NON-DECLARED USE OF THE PRODUCT.


THE REPRODUCTION OF THIS MANUAL OR PARTS THEREOF, IS PROHIBITED.

GENERAL SAFETY INSTRUCTIONS


The manufacturer declines all liability for any operation performed on the machine in disregard of the instructions provided in this manual.


 Before connecting the machine to the power supply, ensure that the voltage and frequency correspond to those indicated on the specifications plate.


 **Always connect the machine to an appropriate high sensitivity differential magnet circuit breaker switch (30 mA).**


 Before performing any cleaning or maintenance operation disconnect the machine from the power supply by:


- 1) Positioning the master switch on OFF;
- 2) Removing the plug.


 Wear gloves to perform maintenance on the motor compartment or on the evaporating unit positioned inside the machine.


 Do not insert screwdrivers or other devices between the guards (fan evaporator protections etc.).

 Do not handle electrical parts with wet hands or without shoes.

 Ensure good functioning of the compressor unit and evaporator by never obstructing the air inlets.

 In the case of machines fitted with wheels, check that the rest surface is flat and perfectly horizontal.

 In the case of machines fitted with locks and keys, it is recommended to keep the keys out of the reach of children.

 Use is only reserved for suitable, trained personnel. Installation, routine and extraordinary maintenance (for example, cleaning and maintenance of the refrigerating system), must be performed by specialised and authorised technical personnel with a sound knowledge of the refrigeration and electrical systems.

1.4. PREREQUISITES SUPPLIED BY THE CUSTOMER

Provide a high sensitivity differential magnet circuit breaker switch (30 mA).

Provide a wall socket with earth of the type used in the country in which the machine is operated.

Verify that the surface on which the machine rests is level.

In the case of water-cooled machines or with equipment with direct humidity control, provide connection to a water system.

1.5. INSTRUCTIONS REGARDING REQUESTS FOR INTERVENTION

Often operating difficulties are a result of ordinary causes which are almost always remediable inhouse, therefore, before requesting assistance from a technician, perform the following simple checks.

If the machine stops operating:

- check that the plug is inserted correctly into the electrical socket.

If the cabinet temperature is insufficient:

- check that this is not being affected by a heat source;
- check that the doors close perfectly;
- check that the condenser filter is not blocked;
- check that the ventilation grills of the control panel are not obstructed;
- check that the items inside the cabinet are not obstructing ventilation.

If the machine is noisy:

- check that there is no loose contact between the machine and another object;
- check that the machine is perfectly level;
- check that the screws (at least those visible) are tightened;

If the problem persists after the above checks request technical assistance, indicating:

- the nature of the defect;
- the code and serial number of the machine appearing on the specifications plate.

1.6. INSTRUCTIONS FOR SPARE PARTS

ORIGINAL SPARE PARTS ARE RECOMMENDED.

The manufacturer does not accept any responsibility for the use of non-original parts.

2. TECHNICAL DATA

The technical data plate is located outside on the side or at the rear and inside the motor compartment.

2.1. NOISE LEVEL

Leq at the noisiest point at 39in/1m in operating conditions < 70 dB(A)
Lpc at 39in/1m in operating conditions < 130 dB(C)

TESTING ENVIRONMENT

Testing was performed in a rectangular showroom with no sound absorption.

Significant obstacles were absent in the area surrounding the machine.

REFERENCE REGULATIONS

Noise testing was performed in compliance with Legislative Decree 277 and in accordance with methods described in ISO 230-5, in order to obtain the data required by 2006/42/EC Directive.

OPERATING CONDITIONS OF THE MACHINE

Testing was performed under the most severe condition which corresponds to the start-up phase called "PULL DOWN".

2.2. MATERIALS AND FLUIDS USED

Respecting the environment, all the used materials comply with Legislative Decree no.151, July 25, 2005, in the implementation of directives RoHS (2002/95/EC) and WEEE (2002/96/EC and 2003/108/EC), concerning the reduction in use of hazardous substances in electrical and electronic equipment as well as waste disposal.

The refrigerant gases or the foaming agents of the polyurethane foams used are in compliance with Regulation EC 842/2006.

3. OPERATION**3.1. APPLICATIONS, PURPOSE, DECLARED AND NON-DECLARED USE, AUTHORISED USE**

Our refrigerators are agri-food machines (EC regulation No. 1935/2004), intended for foodstuffs.

The machines are designed with the appropriate equipment to guarantee the health and safety of the user.

They are not suitable for storing pharmaceuticals, chemicals or any other non food products.

Avoid the appliance misuse. Do not introduce into the cell: live animals, objects or corrosive products.

APPLICATION OF THE BLAST CHILLER-SHOCK FREEZER

The blast chiller-shock freezer is a machine which rapidly lowers the temperature of cooked or raw foods, in order to maintain the organoleptic properties (chemical-physical and nutritional) of these foods unaltered.

COOLING OR FREEZING TIME IS A PARAMETER THAT IS DIFFICULT TO ESTABLISH WITH ANY PRECISION, SINCE THIS DEPENDS ON THE TYPE OF FOOD OR FOODS IN A COOKED DISH.

THE DECLARED PERFORMANCE LEVELS WERE OBTAINED BY USING POTATO PURÉE IN OFF THE SHELF ALUMINIUM TRAYS GN1/1 H=1.6in/40mm. THE THICKNESS OF THE MASHED POTATOES INTO THE CONTAINERS IS 0.98in/25mm.

Blast chilling temperature cycle

This cycle enables rapid lowering of the temperature of the cooked food (from 194°F to 37°F/90°C to 3°C in 90 minutes) to avoid it remaining within the critical temperature range of 50°F to 149°F/10°C to 65°C.

The cooked and blast chilled food can be stored in the refrigerator for up to 5 days.

Shock freezing temperature cycle

Shock freezing (from 194°F to 0°F/90°C to -18°C) prevents the formation of macro-crystals of ice in the food, which would result in a loss of liquids and vitamins. This cycle is suitable for cooked and raw food and conserves these foodstuffs for up to 2 months and 12 months respectively.

Conservation cycle

At the end of every blast chilling or shock freezing cycle the machine envisions a conservation cycle during which the equipment functions as a normal refrigerator and the duration of which is at the user's discretion.

FOODSTUFFS STORAGE

For the best performance of the appliance, the following indications should be observed.

Conservation cycle:

- do not introduce hot foods or uncovered liquids inside the machine;
- wrap or protect foodstuffs, particularly if they contain aromas;
- Arrange the foodstuffs inside so as not to limit air circulation, avoiding placing papers, cartons, boards, etc. on the racks, which may obstruct the passage of air;
- as far as possible, avoid opening the door frequently or for lengthy periods of time.

Blast chilling/shock freezing cycle:

- do not open the door once the cycle has commenced and until the cycle has terminated;
- avoid wrapping, protecting or closing containers with lids or insulating films;
- do not use trays or containers taller than 2.56in/65mm;
- do not stack foodstuffs;
- use aluminium or stainless steel containers.

3.2. DANGEROUS AREAS, RISKS, HAZARDS AND AVOIDABLE RISKS

The refrigerator equipment has been designed and manufactured with the appropriate devices to guarantee the health and safety of the user and does not contain dangerous edges, sharp surfaces or protruding elements.

The stability of the machine is guaranteed even when the doors are open; however, do not pull on the doors.

In the case of refrigerators with drawers, do not open more than one drawer at a time and do not lean or sit on an open drawer, so as to avoid overturning or damaging the refrigerator.

N.B.: In refrigerators with glass doors do not extract more than one basket or rack at a time so as not to compromise the stability of the refrigerator. Gradually arrange the foodstuff starting from the bottom upwards; similarly, remove foodstuff starting from the top downwards.

THE MACHINE HAS NOT BEEN DESIGNED TO BE INSTALLED IN AN EXPLOSIVE ATMOSPHERE.

MAXIMUM LOAD (UNIFORMLY DISTRIBUTED) PER BASKET, DRAWER OR RACK = 88lb/40kg

APPLIANCE WITH WHEELS

When moving, take care not to forcefully push the refrigerator so as avoid overturning and damage. Also note any unevenness of the surface on which the refrigerator is being pushed. Appliances fitted with wheels cannot be levelled, therefore, ensure that the surface on which they rest is perfectly horizontal and level.

 ALWAYS BLOCK THE WHEELS WITH THE STOPS PROVIDED.

RISKS CAUSED BY MOVING PARTS

The only moving part is the fan, which presents no risk as it is isolated by a protection grill secured with screws (before removing this protection, disconnect the machine from the power supply).

RISKS CAUSED BY LOW/HIGH TEMPERATURES

Adhesive labels indicating "TEMPERATURE WARNING" are located in the proximity of areas which constitute low/high temperature dangers.

RISKS CAUSED BY ELECTRICAL POWER

Electrical risks have been eliminated by designing the electrical system in accordance with IEC EN 60204-1 and IEC EN 60335-1.

Adhesive labels indicate "high voltage" areas which may present electrical risks.

RISKS CAUSED BY NOISE

L_{eq} at the noisiest point at 39in/1m in operating conditions < 70 dB(A)
 L_{pc} at 39in/1m in operating conditions < 130 dB(C)


RESIDUAL RISKS

Any liquids emanating from foodstuffs or washing products are prevented from leaking outside by a drain positioned at the bottom.

During cleaning operations, remove the plug and place a collection tray under the machine (Hmax=3.94in/100mm).

IT IS OF UTMOST IMPORTANCE THAT THE PLUG IS REFITTED IN THE HOLE. IN THE CASE OF MACHINES WITH NO DRAIN, PREVENT THE STAGNATION OF LIQUIDS BY CLEANING THOROUGHLY ON A DAILY BASIS.

3.3. SAFETY DEVICES

 IT IS PROHIBITED TO TAMPER WITH OR REMOVE THE SAFETY DEVICES PROVIDED (PROTECTION GRILLS, DANGER LABELS, ETC.). THE MANUFACTURER DECLINES ALL LIABILITY SHOULD THE SAID INSTRUCTIONS NOT BE RESPECTED.

4. ROUTINE AND PROGRAMMED MAINTENANCE

The information contained in this chapter addresses suitable, trained personnel in the case of routine maintenance; while specialised and authorised personnel is addressed for extraordinary and/or programmed maintenance.


4.1. ELEMENTARY SAFETY STANDARDS

Before performing any intervention, disconnect the machine plug from the electrical mains power supply.

REMOVAL OF PROTECTIONS OR SAFETY DEVICES IS PROHIBITED.

In routine maintenance operations, the removal of protections/safety devices (grills, adhesive labels, etc.) is prohibited.

4.2. INSTRUCTIONS REGARDING EMERGENCY OPERATIONS IN THE CASE OF FIRE

 DO NOT USE WATER IN THE CASE OF FIRE. USE CO₂ FIRE EXTINGUISHER (CARBON DIOXIDE) AND COOL THE MOTOR COMPARTMENT AREA AS QUICKLY AS POSSIBLE.

4.3. CLEANING THE MACHINE

Before any cleaning operation, disconnect the machine from the electrical power supply.

INITIAL INSTALLATION

Before operating, wash the interior and accessories with a little water and neutral soap in order to remove the characteristic "new" odour. Arrange the accessories inside the cabinet in positions most appropriate for use.

DAILY CLEANING

Carefully clean the external surfaces of the machine using a damp cloth and following the direction of the finish.

Use neutral detergents and not substances with a chlorine base and/or that are abrasive.

Do not use utensils which may cause scratches and consequently the formation of rust. Rinse with clean water and dry carefully.

Clean the interior of the cabinet with neutral detergents which do not contain chlorine or abrasives, to avoid the formation of dirt residues. In the case of hardened residues, use soap and water or neutral detergents, using a wooden or plastic spatula if necessary.

After cleaning, rinse with a little water and dry carefully.

Do not wash the machine with direct water jets, as any water leakage into electrical components may affect their correct functioning.

Lower and adjoining areas of the machine must also be cleaned on a daily basis with soap and water and not with toxic or chlorine-based detergents.

WARNINGS FOR BLAST CHILLERS WITH WASHING KIT

Always use the neutral detergent supplied by the manufacturer so to guarantee maximum cleanliness without damaging the interior surface and the relative functional parts of the blast chiller (evaporator, fans, heating plant, etc).

Before starting any washing program check, using the visual indicator positioned in the lower left side of the appliance, that the level of detergent is above the minimum accepted.

PERIODIC CLEANING AND GENERAL MAINTENANCE

Cleaning and general maintenance operations must be carried out to ensure the consistent performance of the machine.

The refrigerator unit (condenser) must be cleaned by specialised personnel.

Regularly clean the drain to avoid that the hole becomes blocked.

IT IS OF UTMOST IMPORTANCE THAT THE HOLE IS CLOSED ONCE AGAIN WITH THE APPROPRIATE PLUG.

4.4. PERIODIC CHECKS

- Check that the plug is correctly inserted in the power supply socket.
- Check that the appliances are not affected by heat sources.
- Check that the machine is perfectly level.
- Check that the door gasket seals perfectly.
- Check that the drain is not blocked.
- Check that the condenser battery is not covered with dust; should this be the case, request after-sales technical assistance.

4.5. PRECAUTIONS IN THE CASE OF EXTENDED PERIODS OF INACTIVITY

If an extended period of inactivity of the machine is foreseen:

- switch the machine off by pressing the OFF button on the control panel;
- remove the plug from the power supply socket;
- empty the refrigerator and carefully clean it (see cleaning section);
- leave doors ajar to ensure air circulation.

4.6. EXTRAORDINARY MAINTENANCE (only by specialised personnel)

Periodically clean condenser.

Check door gaskets to ensure perfect sealing.

Check that the electrical system is in order.

Check the surround heating elements (using an amperometric clamp).

IN THE CASE OF REPAIRS OR REPLACEMENT OF PARTS, ALWAYS PROVIDE THE CODE AND SERIAL NUMBER OF THE MACHINE, VISIBLE ON THE SPECIFICATIONS PLATE.

5. DISPOSAL

5.1. DISCONNECTION

The disconnection operations must be done by qualified technicians.

Avoid spilling or leakage into the environment.

Before disconnecting the unit collect, if there are any:

- refrigerant gas;
- non-freezing solutions present in hydraulic circuits.

5.2. STORAGE

Waiting for dismantling and disposal, the appliance can be temporarily stored outdoor provided that the unit electrical, refrigeration and plumb-

ing circuits are intact and closed.

However country's laws on environmental protection are still to be observed.

5.3. DISMANTLING AND DISPOSAL



This symbol identifies the units as returning units, in directive RAEE 2002/96/CE.

Information regarding potential effects on environment and human health, due to the presence of hazardous substances, can be obtained from the manufacturer-distributor-importer, as in charge of collecting and processing the waste, or from the retailer where you purchased the appliance, or from the local services in charge of waste disposal. DISMANTLING OPERATION MUST BE DONE BY QUALIFIED PERSONNEL.

Disposal

WEEE Directive requires that electrical and electronic equipment disposal and recycling must be handled through a dedicated collection, in suitable approved facilities, and in a separate way from the one done for mixed domestic waste disposal.

The user has the obligation of not disposing of the appliance at the end of the useful life of the same, as a domestic waste, but to deliver it to designated collection facilities authorized as required by regulations or specified by the distributor.

All materials are to be retrieved or disposed of in compliance with the national regulations concerning the subject.

For further information on the appliance disposal: contact the manufacturer.

6. INSTALLATION

(only by specialised technical personnel)

6.1. TRANSPORT AND HANDLING OF THE PRODUCT

The machine must be transported using suitable handling equipment and never manually.

If lifting systems are used, such as a forklift or transpallet, take particular care that the load is balanced.

Normally the packaging is in expandable polystyrene on wood pallets, secured to the bottom of the equipment for greater safety during transport and handling.

Warnings are printed on the packaging, representing the instructions to be complied with to ensure that no damage is caused during loading and unloading operations, transport or handling.

Warnings printed on our packaging:



The user must dispose of the packaging in accordance with the laws in force in the applicable country.


STACKING LIMITS

When storing or transporting the machine, the maximum stacking limit is two machines, unless otherwise indicated with an appropriate adhesive label.

SINCE THE CENTRE OF GRAVITY OF THE MACHINE DOES NOT CORRESPOND TO ITS GEOMETRIC CENTRE, BE AWARE OF INCLINATIONS DURING HANDLING.

6.2. DESCRIPTION OF COMMISSIONING OPERATIONS

After removing the packaging from the machine, it is advisable to verify the integrity of the machine and the absence of damage due to transport. Any damage must be communicated to the carrier immediately. Damaged machines cannot be returned to the manufacturer under any circumstances without prior notice and written authorisation is received.

 DURING HANDLING DO NOT PUSH OR DRAG THE MACHINE TO PREVENT OVERTURNING OR DAMAGE TO PARTS (E.G. FEET).


 NEVER LEAN THE MACHINE ON THE DOOR SIDE.


6.3. POSITIONING

Position the machine in a well-aerated place and far from heat sources. Observe minimum gaps for operating functions, aeration and maintenance.

MACHINE WITH WHEELS

A machine with wheels cannot be levelled, therefore, ensure that the surface on which it rests is perfectly horizontal and level.

 AFTER HAVING POSITIONED THE MACHINE, ALWAYS BLOCK THE WHEELS.

 DURING HANDLING DO NOT PUSH FORCEFULLY OR DRAG THE MACHINE TO PREVENT OVERTURNING OR DAMAGE. PAY PARTICULAR ATTENTION TO UNEVENNESS OF SURFACES. NEVER LEAN THE MACHINE FROM THE DOOR SIDE.

 THE MACHINE HAS NOT BEEN DESIGNED TO BE INSTALLED IN EXPLOSIVE ENVIRONMENTS.

6.4. CONNECTION

Before connecting the machine to the power supply, ensure that the voltage and frequency correspond with those indicated on the specifications plate.

A variation of +/-10% of the normal voltage is permitted.


It is of utmost importance that the machine is connected to an efficient earth connection.


WARNINGS FOR BLAST CHILLERS WITH WASHING KITS

The appliance must be connected to the water supply network using the supplied flexible pipe, suitable for high temperatures and pressure and with 3/4" GAS attachment.

To prevent the excessive deposit of lime scale and therefore decrease plant maintenance the use of a water softener is recommended.

To increase efficiency the recommended water temperature must be between 40-60°C. The optimum network pressure must be between 2-5 bar for the rotor to rotate regularly. If the water pressure should fall below 0.5 bar a safety pressure switch will intervene that will immediately block the function, with signal on the alarm display.

 **For blast chillers with washing kit**
IT IS FUNDAMENTAL NOT TO CHANGE THE DIRECTION OF THE ROTOR SPRAYING NOZZLES SO AS NOT TO COMPLETELY ALTER THE SYSTEM FUNCTIONING FEATURES.

 DO NOT USE PLUGS WITHOUT EARTH. THE MAINS SOCKET MUST COMPLY WITH REGULATIONS VALID IN THE APPLICABLE COUNTRY.

EARTHING THE MACHINE IS A MANDATORY SAFETY MEASURE BY LAW

In order to protect the machine from any electrical overload or short-circuits, the connection to the power supply is through a high sensitivity differential magnet circuit breaker switch (30 mA) with manual re-set and with sufficient power.

For dimensioning the protection device, consider the following:

$I_{max} = 2.3 I_n$ (nominal current)

I_{cc} (short-circuit current) = 4500 A with 120v/1~/50Hz

230v/1~/50Hz power supply.

I_{cc} (short-circuit current) = 6000 A with 208-230v/3~/60Hz

400v/3~/50Hz power supply.

6.5. RE-INSTALLATION






If a re-installation is necessary, proceed as follows:

- 1) Position the power supply switch on OFF;
- 2) Disconnect the plug from the power supply and wind up the cable;
- 3) Remove all foodstuff from the interior of the cabinet and clean the cabinet and accessories thoroughly;
- 4) Re-pack the machine, taking care to re-position the protective polystyrene and secure the wooden base, in order to prevent damage during transport;
- 5) Proceed as described previously for the new positioning and connection.

7. USER INSTRUCTIONS


7.1. CONTROL PANEL

Description of control panel keys

-  **ON /OFF**
On/off control board
-  **START/STOP**
Start/stop blast chilling/shock freezing cycles
-  **+37°F SOFT BLAST CHILLING**
Selection of +37 soft blast chilling cycle
-  **+37°F HARD BLAST CHILLING**
Selection of +37 hard blast chilling cycle
-  **0°F SOFT SHOCK FREEZING**
Selection of 0°F soft shock freezing cycle
-  **0°F HARD SHOCK FREEZING**
Selection of 0°F hard shock freezing cycle
-  **DEFROST**
Start/stop defrost
By pressing the key for extended time, the temperature of the evaporator probe is displayed
-  **HEATING PROBE**
Heating for core probe extraction
-  **UVC STERILISATION**
UVC light activation for cabinet sterilisation
-  **MULTI-POINT/MULTIPROBE PIN PROBE**
Visualizes the temperature of the core probe
Extended pressing displays the 4 temperatures
Excludes the automatic cycle
-  **PRECOOL**
Start/stop precool cycle
-  **FANS SPEED**
Set fans speed during cycle
-  **PROGRAM**
Memory or recalls a blast chilling/shock freezing cycle on memory
Selects infinite time cycle
-  **HACCP ALARMS RECALL**
Enter/exit HACCP menu
-  **UP**
Increases. During blast chilling/shock freezing it displays the time elapsed from start of cycle for a few seconds
-  **DOWN**
Decreases. During blast chilling/shock freezing it displays the time elapsed from start of cycle for a few seconds



Description of the display and symbols



DISPLAY 1















Displays core probe temperature or time and selected washing cycle

DISPLAY 2

Displays temperature of the cabinet

DISPLAY 3


Displays the operational phase in progress (1-3)
Number of core probe inserted in core

-  Cabinet temperature
-  Core probe heating active
-  Blast chilling/shock freezing cycle with core probe (flashing in core probe insertion test)
-  Multipoint probe automatic freez./chill. cycle (flashing during pin insertion test)
-  Blast chilling/shock freezing cycle with timer
-  Sterilisation in progress
-  Blast chilling cycle function selected (+37°F)
-  Shock freezing cycle function selected (0°F)
-  Hard phase selected
-  Blast chilling in progress (flashing active compressor delay)
-  Conservation phase in progress
-  **STOP** Machine in Stop mode
-  **HACCP** HACCP alarm
-  **PRECOOL** phase

GENERAL RECOMMENDATIONS



For correct use of the core probe:

- Avoid violent blows, they can jeopardise the correct functioning of the probe.
- Sterilise the core before use.
- The maximum recommended thickness of the product is 45mm.
- Cleanliness of the core determines good performance.




TO INSERT THE PROBE

- insert the probe with the point as near as possible to the heart of the product.
- only insert the shiny part.



TO EXTRACT THE PROBE

- Heat the probe (☀️ or 🔁 key), see 7.3.8.
- Turn it.
- Extract it without tilting the needle.




7.2 CLOCK PROGRAMMING ACCORDING TO HACCP

When machine is off, press buttons (+37°F) and simultaneously for an extended time, clock modification can be accessed.

DISPLAY1 indicates the last figure of the year.

DISPLAY2 indicates the letters "yy".

Press or to respectively modify:



Press the key to confirm the value entered and pass on to the next value.

Exit from the clock menu occurs automatically after 60 seconds or by pressing the +37°F key.

7.3 OPERATIONAL CYCLES

7.3.0. SWITCH ON




(Fig.1)

By pressing the key the board switches on. No selection is visible in DISPLAY 1 (Fig.1).

DISPLAY 2 indicates the cabinet temperature.

7.3.1. PRE-COOLING



(Fig.2)

Select the desired blast chilling cycle / / (+37°F) / (0°F).


The pre-cooling cycle is started by pressing the key (Fig.2).

On reaching the temperature, the buzzer is activated; the chamber is ready to perform a blast chilling cycle. By opening the door or pressing the key, the pre-cooling cycle is interrupted, the machine re-proposes the last cycle selected. Introduce the product and start up the cycle by pressing the key.

7.3.2. +37°F SOFT OR HARD BLAST CHILL CYCLE AND 0°F SOFT OR HARD SHOCK FREEZING USING CORE PROBE

BLAST CHILLING/SHOCK FREEZING PHASE

Press the button to select the +37°F soft blast chilling cycle and the button for the +37°F hard cycle.



(Fig.3)

Press the button to select the 0°F soft shock freezing cycle and the button for the 0°F hard cycle. DISPLAY 1 shows the core probe temperature.

DISPLAY 2 shows the cabinet temperature.

DISPLAY 3 shows A for Automatic (Fig.3).

The following symbols light up: core probe , type of blast chilling or or

or , temperature and **STOP**. When button is pressed, the A for Automatic will disappear.



(Fig.4)


To start the selected cycle press the key and the blast chilling symbol lights up (Fig.4). Within the first 3 minutes, the electronic control performs a core probe insertion test to verify the effective application of the probe in the product to blast chill (flashing core probe symbol); there is no control of the room temperature, during this period. If the core probe is inserted badly or left in the holder provided, the cycle is automatically converted to timed.

During a timed blast chilling cycle (Fig.5):

DISPLAY 1 indicates the time to the end of the cycle itself;

DISPLAY 2 indicates the cabinet temperature;

DISPLAY 3 indicates the blast chilling phase in progress.



(Fig.5)

If the core temperature has not been reached within the time determined, the time out alarm is activated.

The blast chill phase continues but the and HACCP symbols flash and the alarm is memorised HACCP archives. The code AL5 flashes on DISPLAY 1 (Fig.6).

The alarm is automatically cancelled when passing to the conservation phase and the **HACCP** symbol remains on.



(Fig.6)

By pressing at any time during the cycle in progress, the time from the start of blast chilling is


indicated. Press the multi-point button for extended time to display the temperature of the 4 sensors in succession on DISPLAY 2 and the corresponding number of the sensor on DISPLAY

The undetected inserted sensor is displayed in DISPLAY 3 with the symbol. Upon termination of the blast chilling cycle the machine automatically continues on to the conservation phase, see 7.3.8.


By pressing the it is possible to visualize the elapsed time from the beginning of the cycle.

To modify fan speed see 7.3.6.


+37°F SOFT




+37°F HARD



0°F SOFT



0°F HARD



7.3.3. +37°F SOFT OR HARD BLAST CHILLING CYCLE AND 0°F SOFT OR HARD SHOCK FREEZING WITH TIMING

BLAST CHILLING/SHOCK FREEZING PHASE

Press the key twice to select the +37°F soft blast chilling cycle and the key twice for the +37°F hard cycle.

Press the key twice to select the 0°F soft shock freezing cycle and the key twice for the 0°F hard cycle.



(Fig.7)

DISPLAY 1: indicates the total time foreseen for blast chilling/shock freezing (Fig.7).
 DISPLAY 2: indicates the cabinet temperature.

The following symbols light up , time , type of blast chilling soft or hard or shock freezing soft or hard temperature and **STOP** .

Press or to change the cycle duration.

N.B.: It is possible to set duration either shorter or longer that 90 min. for blast chilling cycles or 240 min. for shock freezing cycles.

Maximum limit: 120 min. for the +37°F cycle.

Maximum limit: 300 min. for the 0°F cycle.

Press the key to start the cycle.




(Fig.8)

By pressing key (Fig.8) the temperature read by the core probe is temporarily displayed (if inserted into the product, it will show the temperature of this product). On termination of the blast chilling/shock freezing cycle the machine automatically progresses to the conservation phase, see 7.3.8.


By pressing the key it is possible to visualize the elapsed time from the beginning of the cycle.

To modify fan speed see 7.3.6


+37°F SOFT




+37°F HARD




0°F SOFT



0°F HARD





7.3.4. AUTOMATIC BLAST CHILL/SHOCK FREEZE CYCLE WITH MULTI-POINT PIN PROBE SUITABLE FOR PRODUCTS WITH THICKNESS OVER 90 MM. A




(Fig.9)

Insert the core probe with the first sensor as far as possible into the core of the product. Select the desired cycle +37°F soft or hard or 0°F hard by using the appropriate keys DISPLAY 3 indicates A for Automatic.






When button  is pressed, the blast chilling symbol , lights up. DISPLAY 3 indicates the number of the hottest sensor selected by the control, while DISPLAY 1 indicates the temperature of this sensor. Within the first 3 minutes, the electronic control performs a core probe insertion test to verify the effective application of the probe in the product to blast chill (flashing core probe symbol); there is no control of the room temperature, during this period. If the core probe is inserted badly or left in the holder provided, the cycle is automatically converted to timer.

Through functions controlled by the circuit board, the cycle terminates when the temperature of the probe at the core reaches the value set (+37°F for blast chilling, 0°F for shock freezing). Upon termination of the blast chilling cycle the machine automatically continues to the conservation phase, see 7.3.8.

By pressing the  key it is possible to display the duration of the blast chilling/shock freezing cycle just concluded. To modify fan speed see 7.3.6.

7.3.5. BLAST CHILL / SHOCK FREEZING CYCLE WITH 2 – 3 – 4 STANDARD NEDLE PROBES

This cycle can be run with several standard single-point core probes.

Select the cycle desired, e.g.:  or  (+37°F) or  or  (0°F) then press the  key to start the cycle.



(Fig.10)

When the temperature of a probe reaches the value set for the blast chilling/shock freezing cycle selected, this is signalled by buzzer. DISPLAY 3 flashes the number of the relevant core probe (Fig.10). If in the meantime the other probes reach core temperature, the signal is placed in a queue.

The signals terminate and the buzzer switches off only when the door is opened.

Once the door is closed and the other probes reach core temperature, a new signal appears on DISPLAY 3 (Fig.11), which indicates the number of the probe with the blast chilled/shock frozen product.

If blast chilling is not complete within the determined time, the buzzer activates for one minute and can be switched off by pressing any key.




(Fig.11)

The blast chilling phase continues but the clock and HACCP symbols flash and the alarm is memorised in the HACCP records. The AL5 code flashes on DISPLAY 1 (Fig.12).





The alarm cancels automatically when passing to the conservation phase and the HACCP symbol remains on. Upon termination of the cycle the machine automatically proceeds to the conservation phase. see 7.3.8.



(Fig.12)



By pressing the  key it is possible to display the duration of the blast chilling/shock freezing cycle just concluded. To modify fan speed see 7.3.6.

7.3.6. EVAPORATOR FAN SPEED SETTING

With the cycle started it is possible to modify fan speed by pressing the  key. The display will show the speed value as a percentage. Use  or  to set the new value (min 30% - max 100%) and then confirm using the  key.

7.3.7. CUSTOMISED BLAST CHILLING OR SHOCK FREEZING CYCLES "A",  

It is possible to modify the blast chilling/shock freezing cycle:

- automatic **A**,
- timed 
- probe 

customising them as required.

The blast chilling/shock freezing cycle is divided into three phases, each characterised by four sets, of which the following values can be modified:

IN ORDER TO MODIFY THE DATA IN A NON-PERMANENT WAY



Press the relevant key  /  /  (+37°F) /  (0°F) for extended time.

a - set cabinet temperature phase 1/2/3/4







(Fig.13)

The control displays (Fig.13):
 SCREEN 1 - modifiable cabinet temperature
 SCREEN 2 - no signal (off)
 SCREEN 3 - the phase number

The cabinet temperature symbol  flashes. By pressing  or  the value of the set temperature is increased or decreased.

b - set % fan/cabinet rotation speed phase 1/2/3/4

By pressing  or  again, the number 100 appears. By pressing the  or  key the value of the set % value of the rotation speed of the cabinet fan/s increases or decreases.

c - set core temperature phase 1/2/3





By pressing  again, the core symbol  , By pressing the  or  key the value of the set core temperature increases or decreases.


d - set duration phase 1/2/3

By pressing  again, the clock symbol  flashes. By pressing  or  the set time value increases or decreases.


Repeat the same procedure described for the successive phases 2 and 3.


Phase 4 of conservation only envisions setting the set temperature, % fan speed.

To confirm the settings of all the phases described, press the relevant key  /  /  (+37°F) /  (0°F) for extended time.

Press the  key to start the cycle.

At the end of the cycle the machine moves into conservation phase automatically, see 7.3.8.

By pressing  the display shows the duration of the cycle just finished, and it can be memorised as described in ch. 7.3.9.

The new settings of the customised cycle will be lost when the machine is stopped using the .



See tecincal manual S __ = setpoint	BLAST CHILLING OR SHOCK FREEZING			CONSERVATION
	PHASE 1	PHASE 2	PHASE 3	PHASE 4
SET CABINET	S01	S04	S07	S10
SET FAN SPEED	S50	S51	S52	S53
SET CORE	S02	S05	S08	- -
SET TIME	S03	S06	S09	- -


IN ORDER TO MODIFY THE DATA IN PERMANENT WAY (see technical manual)

7.3.8. INDEFINITE TIME CYCLE WITH CABINET SET POINT SETTING









(Fig.14)




Press the  key to exit any program. Press the key once again and DISPLAY 1 will show P0 and the clock symbol  (Fig.14).




(Fig.15)

Select a blast chilling or shock freezing program using the appropriate keys +37°F soft  or 0°F  soft. DISPLAY 1 shows the infinity symbol **888** with the clock symbol , the type of blast chilling  or shock freezing , the temperature symbol  and **STOP**

next to it. DISPLAY 2 shows the default temperature of the selected cycle (Fig.15).

By pressing  or  it is possible to increase or decrease the cabinet set temperature value shown in. DISPLAY 2. To start or stop the machine press the  key.

7.3.9. CONSERVATION PHASE




(Fig.16)


The machine proceeds to conservation phase when at the end of every blast chilling/shock freezing cycle.

DISPLAY 1 is off



DISPLAY 2 indicates the cabinet temperature (Fig.16).

The conservation symbol  is on.

By pressing the  key, the duration of the blast chilling/shock freezing cycle is displayed.

This phase is terminated by pressing the  key.

The machine sets itself on Stand-by and the user is asked whether the program is to be

memorised or the  key must be pressed again. Press the core probe heating key  to facilitate extraction of the probe from the product (after shock freezing).



The  symbol lights up on the display

Heating takes place only if the temperature of the core is less than +32°F.

7.3.10. MEMORISING A BLAST CHILL/SHOCK FREEZE PROGRAMME






(Fig.17)

Press the  key when the machine is in conservation mode. DISPLAY 1 shows the number of the first free program. When the  key is pressed, the cycle is memorised and the control positions itself to re-start with a new cycle (Fig.17).

It is possible to cancel a memorised program by overwriting it with a new blast chilling/shock freezing cycle as follows: at the end of the cycle instead of memorising it on the first free program automatically




(Fig.18)





selected by the system, use the  or  key and go to the number of the program to cancel and press the program key .

If the **- - -** symbols appear on DISPLAY 2 (Fig.18) next to the number, it means that there is no program memorized.

7.3.11. RECALL OF MEMORISED BLAST CHILLING/SHOCK FREEZING PROGRAM



(Fig.19)


To select a memorised blast chilling/shock freezing program, press the  key. By pressing the  or  key the memorised programmes are displayed in sequence. Press the  key, to start the selected blast chilling/shock freezing program. If DISPLAY 2 (Fig.19) indicates the **- - -** symbols, it means that there are no programs memorized.

7.4. DEFROSTING



(Fig.20)

Defrosting takes place if the cabinet temperature is below parameter P57 (see technical manual).



To start a defrosting cycle press the  key for extended time with the machine in **STOP** door open mode. DISPLAY 1 shows *def* and DISPLAY 2 the cabinet temperature (Fig.20).

7.5. STERILISATION (optional)



(Fig.21)

Sterilisation can commence only if the temperature is above parameter P26 (see technical manual).

The cycle is activated with the machine in Stand-by by pressing the  key. The cycle ends when the key is pressed again. The  symbol lit on the display, indicates that the sterilisation phase is in DISPLAY 1 shows the time to the end of the process. If the door is opened or a blackout occurs, process. sterilisation is interrupted (Fig.21).

7.6. PRINTER (optional)

If the printer is present, the following is recorded for every blast chill cycle: date, time, type of cycle, time elapsed from start of cycle and cabinet and core temperature sampled every 10 minutes. For recording lower or higher than 10 minutes, change the parameter P44 (see technical manual). Using parameter P86 (see technical manual) the language of the printer can be changed.

*****HELLO*****						
03/03/2007		10:15				
+37°F HARD						
Time	Ti	SP1	SP2	SP3	SP4	
00:00	25	54	52	51	49	
00:10	8	45	44	42	40	

Time = time elapsed

Ti = **CABINET** temperature

SP1 = MULTIPOINT Core PROBE SENSOR 1 ETC

SP2 = MULTIPOINT Core PROBE SENSOR 2 ETC

SP3 = MULTIPOINT Core PROBE SENSOR 3 ETC

SP4 = MULTIPOINT Core PROBE SENSOR 4 ETC

7.7. ALARMS/ERRORS


7.7.0. ALARM ABSENCE COMMUNICATION BETWEEN BASE AND KEYBOARD



====> CONTACT AFTER-SALES TECHNICAL ASSISTANCE

Verify connections, switch the machine on and off disconnecting the power supply

7.7.1. HIGH TEMPERATURE ALARM



During the positive (negative) conservation phase, the alarm intervenes when the cabinet temperature exceeds the set values.

Alarm code AL1 will flash on DISPLAY 1.

The buzzer sounds but can be stopped by pressing a key. When the temperature falls below the alarm threshold, the alarm is automatically cancelled.

7.7.2. LOW TEMPERATURE ALARM




During the positive (negative) conservation phase, the alarm intervenes when the cabinet temperature exceeds the values set.

Alarm code AL2 will flash on DISPLAY 1.


The buzzer sounds, but can be stopped by pressing a key. When the temperature rises above the alarm threshold, the alarm is automatically cancelled.

7.7.3. DOOR OPEN ALARM



If the door is open for more than two minutes after the start of the blast chilling/shock freezing cycle, the compressor stops and the code AL3 will flash on DISPLAY 1.

7.7.4. PRESSURE SWITCH/ELECTRIC ALARM



====> CONTACT AFTER-SALES TECHNICAL ASSISTANCE


When the alarm AL4 is activated, the blast chilling cycles in progress will be immediately terminated.

7.7.5. TIME-OUT ALARM



If the blast chilling or shock freezing phase in progress do not terminate within the set time, alarm AL5 will flash on DISPLAY 1.

7.7.6. BLACKOUT ALARM



If a blackout occurs during a blast chill cycle, the machine remembers the cycle and phase it was performing when it switched off.

In cycles with core probes, the machine also remembers which probes were inserted.

Blast chill time tolerance is 10 minutes.

Alarm AL7 will flash on DISPLAY 1.


The buzzer sounds but can be stopped by pressing a key. If the key is pressed again, the display disappears.

7.7.7. LOW PRESSURE WATER ALARM



If the water pressure in the supply network is below 0.5 bar the alarm message 'AL8' appears which will not allow any washing program to be sent.

7.7.8. CABINET PROBE ALARM



====> CONTACT TECHNICAL ASSISTANCE

The cabinet probe measures the temperature of the cabinet, which is indicated on DISPLAY 2.

If the probe fault causes an alarm, the buzzer is and error code ER1 flashes on the DISPLAY 1.

The buzzer sounds, but can be stopped by pressing a key.

Once the fault is remedied, the alarm cancels automatically.

- If the cabinet probe is broken, it is nevertheless possible to start or continue a timed blast chilling program.

- A temperature blast chilling program not yet started, will switch-over the start to timed.


- A blast chilling program in progress if the core probe is not inserted, switches-over with time.

The compressor control is determined by the core probe instead of by the cabinet probe.

- A blast chilling program in progress with the core probe inserted switches the compressor on and off on the basis of previously memorized times in blast chilling or conservation modes.

7.7.9. CORE PROBE ALARM

====> **CONTACT AFTER-SALES TECHNICAL ASSISTANCE**



The core probe is used for core blast chilling cycles. A fault in the core probe causes an alarm only if a blast chilling cycle is in progress with core temperature control.

In this case the cycle automatically switches-over to time and the buzzer is activated.

Alarm code ER2 will flash on DISPLAY 1.

The buzzer sounds, but can be stopped by pressing a key.


The alarm code display disappears by pressing a key.

Core PROBE ALLARM:



7.7.10. EVAPORATOR PROBE ALARM

====> **CONTACT TECHNICAL ASSISTANCE**



The probe allows termination of defrosting based on temperature.


Press and release the  key, to see the temperature of the evaporator, which is shown on DISPLAY 2.

A faulty probe causes a probe alarm of the evaporator probe and the buzzer is activated. The error code ER7 flashes on the display.

7.8. HACCP

When the HACCP symbol flashes, it means that a new HACCP alarm has occurred.

In order to view the alarm, access HACCP alarm display by pressing the HACCP key .



Display 1 indicates the alarm type 'AL1'

Display 2 indicates 'A L'

Display 3 indicates the position of alarm '4'

The HACCP symbol is on.

If the alarm is for High/Low temperature, the thermometer symbol  is on.

If the alarm is for Time-Out or Blackout, the clock symbol  is on.

The illustration indicates that the last alarm was due to high temperature and 4 is the position in the alarm memory. 10 HACCP alarms can be memorised and allocated to positions from 0 to 9. The UP and DOWN buttons can be used to scroll through the memorised alarms.

By pressing the  key, access the display of the alarm start date:



Display 1 indicates the day on which alarm '15' started


Display 2 indicates 'dd'

Display 3 indicates the alarm number '4'

By pressing the  or  key the day and time can be seen:



"tt" max=999



If the alarm is for low or high temperature, the display after the date is the minimum or maximum temperature reached:


Display1 indicates maximum temperature '14'

Display2 indicates 'H t' or 'L t'

Press the  key to exit from the alarm start date display and return to alarms display.

The memorised HACCP alarms are:






- High temperature alarm in conservation phase;
- Blast chilling cycle time-out alarm;
- Low temperature alarm in conservation phase;
- Blackout alarms.

Press the  key to exit the HACCP menu.


Once the HACCP alarm has been displayed, the **HACCP** symbol no longer flashes and remains off until a new HACCP alarm occurs.

7.8.1 HACCP ALARM RE-SET

It is possible to cancel HACCP alarms memory.

- Switch control board off using the  key.
- Press simultaneously the  and  keys simultaneously for extended time.
- 'RES HACCP' appears on the display.
- Press the  and  keys simultaneously for extended time.

7.8.2 RICS SOFTWARE CONNECTION



Modify the following parameters:

P40 = 1, 2, 3,... (address of each device)

P41 = 2

P42 = 1 o 2 (1=BaudRate 4800; 2=BaudRate 9600)

P43 = 2

Refer to the manual of the software present in the cd.



110 Woodcrest Road, Cherry Hill, NJ 08003

Phone: (856) 428-4200 Fax: (856) 673-0038 Website: www.victoryrefrigeration.com

E-Mail: parts@victoryrefrigeration.com order-entry@victoryrefrigeration.com service@victoryrefrigeration.com